

AlphaMINDS Conning and Docking

Installation and Operation Manual

www.alphatronmarine.com

Contents

I.	Preface.....	5
	Revision History	6
	Glossary	7
	Abbreviations.....	7
	Definitions.....	9
II.	Safety Information.....	11
III.	Warranty.....	12
1	Introduction.....	13
2	Intended use.....	14
3	General description	15
3.1	System overview	15
3.2	Hardware	16
3.2.1	AlphaMINDS computer.....	16
3.2.2	AlphaMINDS USB dongle	16
3.2.3	Monitor (optional).....	16
3.2.4	External devices.....	16
3.3	Software	18
4	Operation	19
4.1	HMI overview	20
4.1.1	Top bar items.....	21
4.1.2	AlphaMINDS Conning application	26
4.1.3	AlphaMINDS Docking application.....	32
5	Installation.....	46
5.1	Initial inspection	46
5.2	Installing the system.....	46
5.2.1	General installation requirements	46
5.2.2	Power requirements.....	46
5.2.3	Grounding availability.....	47
5.2.4	Connecting the system	47
5.3	Commissioning and testing	47
6	Settings	49
6.1	Units	51

6.2	Range & Style	52
6.3	AIS.....	53
6.3.1	Features.....	53
6.3.2	Filters	54
6.3.3	Settings	55
6.4	Sensor Settings	56
6.4.1	AIS.....	56
6.4.2	Anemometer	56
6.4.3	Auto Pilot.....	56
6.4.4	Bow Thruster	56
6.4.5	Climate meter	58
6.4.6	Distance Above Water	58
6.4.7	Distance Below Water	58
6.4.8	ECDIS.....	59
6.4.9	Echo Sounder.....	59
6.4.10	Engine & Shaft	59
6.4.11	GPS.....	60
6.4.12	GPS Compass	60
6.4.13	Gyro Compass.....	60
6.4.14	Magnetic Compass	60
6.4.15	Rudder	60
6.4.16	Speed Log	61
6.4.17	Stern Thruster.....	61
6.4.18	Turn Indicator	61
6.4.19	Vessel Clock	61
6.5	Vessel Settings.....	62
6.5.1	Vessel Info	63
6.5.2	CCRP Position.....	64
6.5.3	GPS Position.....	64
6.5.4	GPS Compass Position	64
6.5.5	Distance Sensor Position	64
6.6	System Settings	65
6.6.1	Apps	65
6.6.2	Display	65

6.7	Network Settings	66
6.8	Docking Settings	68
6.9	Chart Settings	70
7	Troubleshooting	72
7.1	Mitigation	72
7.2	Support page	72
7.2.1	Line Monitor	73
8	Help & Support	74
	Appendices	75
	Appendix A: Specifications	75
	Appendix B: AlphaMINDS inputs	76
	Appendix C: AlphaMINDS alerts	78
	Appendix D: DOP values and their rating	80



I. Preface

AlphaMINDS Conning & Docking is a high-end vessel monitoring solution that enables safer and more efficient maritime operations.

This manual provides information required for operation.

- Thoroughly read this manual before installation and operation of the equipment.
- We recommend keeping this manual nearby the equipment to ensure ready access to it.

Contact the Alpatron Marine dealer for copies of this manual.

Revision History

Revision No.	Date	Description	Author
1.0	07-04-2023	First version	J. Kreeft

Glossary

The glossary contains a list of abbreviations and a list of definitions.

Abbreviations

Abbreviations as used in this manual are explained in the table below.

Abbreviation	Description
AIS	Automatic Identification System
AMS	Alert Management System
ASM	Application Specific Message
AToN	Aid to Navigation
AWFW	Above Water Forward
AWPSB	Above Water Port Side Bow
AWSBB	Above Water Starboard Bow
AWPSS	Above Water Port Side Stern
AWSBS	Above Water Starboard Stern
AWBW	Above Water Backward
BNWAS	Bridge Navigational Watch Alarm System
BOA	Breadth Overall
BRG	Bearing
BWFW	Below Water Forward
BWPSB	Below Water Port Side Bow
BWSBB	Below Water Starboard Bow
BWPSS	Below Water Port Side Stern
BWSBS	Below Water Starboard Stern
BWBW	Below Water Backward
CCRP	Consistent Common Reference Point
COG	Course Over Ground
CPA	Closest Point of Approach
DOP	Dilution of Precision
ECDIS	Electronic Chart Display and Information System
ENC	Electronic Nautical Charts
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
HDG	Heading
HDOP	Horizontal DOP
IEC	International Electrotechnical Commission
INS	Integrated Navigation System
LOA	Length Overall
MINDS	Multifunctional Information Navigation Display System
MMSI	Maritime Mobile Service Identity
NMEA	National Marine Electronics Association
RTCM	Radio Technical Commission for Maritime Services
RTK	Real Time Kinematic
ROT	Rate of Turn
SAR	Search and Rescue

Abbreviation	Description
SART	Search and Rescue Transmitter
SBAS	Satellite-based Augmentation Systems
SOG	Speed Over Ground
SPD	Speed
STW	Speed Through Water
TCPA	Time to the Closest Point of Approach
VRS	Virtual reference stations

Definitions

The meaning of standard definitions as used in this manual are explained in the table below.

Definition	Description
AlphaMINDS Conning and Docking	Product made by Alpatron Marine.
Automatic Identification System (AIS)	AIS provides a means of broadcasting navigation information including vessel position, speed, heading, dimension, name, destination, ROT, aids to navigation, base station reports and more. It is used by vessel traffic monitoring and control locations throughout the world to improve situational awareness and help prevent collisions at sea.
AIS base station	An onshore AIS unit that monitors traffic in the waterways.
AIS Real AtoN	An AIS Message 21 transmitted from an AtoN that physically exists.
AIS Virtual AtoN	An AIS Message 21 transmitted for an AtoN that does not physically exist.
Aid to Navigation (AtoN)	Any sort of signal, markers or guidance equipment which aids the traveler in navigation, usually nautical or aviation travel. Common types of such aids include lighthouses, buoys, fog signals, and day beacons.
Alert	An alert provides information about a defined state change in connection with information about how to announce this event in a defined way to the system and the operator. Alerts are divided in four priorities: emergency alarms, alarms, warnings and cautions. (ref IEC61162).
Bow	The front of a vessel.
CCRP (Consistent Common Reference Point)	A location on a vessel, to which all horizontal measurements, such as target range, bearing, relative course/speed, closest point of approach, or time to closest point of approach are referenced.
Chart	Nautical term for maps used in nautical navigation that show the depth of waters as well as land boundaries and other obstructions. Charts may be paper or electronic and electronic charts may be of a raster or vector type.
Closest Point of Approach (CPA)	Own vessel calculated distance that will occur in case of no change in course and speed.
Course	The direction a boat is being steered.
Course Over Ground (COG)	The direction of the track of the vessel over the ground, based on position changes.
Current	The flow of water characterized by direction and speed. Current speed and direction may change with the tide.
Depth	In the ECDIS, depth is water depth relative to the keel.
Dilution of Precision (DOP)	A term used in satellite navigation and geomatics engineering to specify the error propagation as a mathematical effect of navigation satellite geometry on positional measurement precision.
Draft	The vertical distance between the waterline and the bottom of the hull (keel).
Drift	The cumulative effect of wind and current on the vessel.

Definition	Description
Electronic Chart Display and Information Systems (ECDIS)	A hardware/software/data marine navigation system that meets the specifications of the International Hydrographic Organization (IHO). An ECDIS is the only electronic system allowed to replace paper charts under the International Convention for the Safety of Life at Sea (SOLAS).
Electronic Navigation Chart (ENC)	An electronic data file containing information that could be used to display a chart. The ENC contains all the chart information necessary for safe navigation and may contain supplementary information in addition to that contained in the paper chart (for example sailing directions) which may be considered necessary for safe navigation.
Forward	Toward the front of a vessel or further ahead of a location
Global Positioning System (GPS)	A worldwide radio-navigation system. It is widely used in marine, terrestrial navigation and location based services. The system uses satellites or a surface signal to locate the vessel with a very high degree of accuracy. The term GPS is frequently used to refer to GPS receivers.
Horizontal DOP (HDOP)	The effect of the DOP on the horizontal position value. The more good visible satellites low in the sky, the better the HDOP and the horizontal position (Latitude and Longitude) are.
Heading (HDG)	The direction the vessel is oriented.
Lynx	Automation and connecting platform developed by Alpatron Marine.
Maritime Mobile Service Identity (MMSI)	MMSI Numbers are a series of nine digits transmitted over a DSC radio path in order to uniquely identify vessel stations, vessel earth stations, coast stations, coast earth stations and group calls. These identities can be used by telephone and telex subscribers connected to the general telecommunications network principally to call vessels automatically.
National Marine Electronics Association (NMEA)	An organization committed to enhancing the technology and safety of electronics used in marine applications. NMEA 0183 is a combined electrical and data specification for communication between marine electronics. It has been defined and is controlled by the NMEA. Alpatron uses the international standard IEC-61162, which is partly derived from NMEA 0183 but is recognized by the IMO for serial data communication
OpenBridge	A Design Guideline for the User Interface of maritime equipment.
Rate of Turn (ROT)	The number of degrees of heading change per unit of time.
Stern	The rear of a vessel.
Time to Closest Point of Approach (TCPA)	The time remaining until the closest point of approach of a target.

II. Safety Information

The signal words DANGER, WARNING and CAUTION used in this manual indicate the degree of hazard that may be encountered by the user. These words are defined as follows:

**DANGER**

Indicates a hazardous situation which, if not avoided, will result in death or serious injury. This signal word is limited to the most extreme situations.

**WARNING**

Indicates a hazardous situation which, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

**NOTICE**

Indicates information considered important but not related to injury. It is typically used to prevent damage to equipment or property.

To safely operate this system, the following DANGERS, WARNINGS, and CAUTIONS must be adhered to. Failure to comply with the precautions or with specific dangers, warnings, and cautions elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment. ALPHATRON MARINE assumes no liability for the customer's failure to comply with these requirements.

**WARNING**

DO NOT DISASSEMBLE OR MODIFY THE EQUIPMENT. OTHERWISE, IT MAY CAUSE A FIRE, OR YOU MAY SUFFER AN ELECTRICAL SHOCK.

**WARNING**

IMMEDIATELY TURN OFF THE POWER AND DISCONNECT THE POWER SUPPLY CABLE IF THE EQUIPMENT IS GENERATING ANY SMOKE OR ODOUR OR IS OVERHEATED. IMMEDIATELY INFORM YOUR LOCAL SERVICE AGENT OF THE SYMPTOM TO HAVE IT REPAIRED. PROLONGED EQUIPMENT OPERATION UNDER SUCH A CONDITION CAN CAUSE A FIRE OR ELECTRIC SHOCK.

III. Warranty

To not to adversely affect the warranty, the following notices must be adhered to.



NOTICE

The AlphaMINDS computer must be installed in accordance with the installation methods described in the manual of the computer. Acting otherwise will void the warranty.



NOTICE

Installation of this product shall only be done by a certified installation company approved by either ALPHATRON MARINE or by an official ALPHATRON MARINE distributor. Acting otherwise will void the warranty.



NOTICE

This product contains no operator serviceable parts. Service and repair shall only be carried out by personnel trained and certified by ALPHATRON MARINE.



NOTICE

Any modification to this equipment without prior written permission from ALPHATRON MARINE will void the warranty.



NOTICE

Operating personnel must not remove equipment covers. Only personnel trained and certified by ALPHATRON MARINE must make component replacement and internal adjustments.



NOTICE

Operating personnel must not disassemble or modify the equipment. Failure to observe this instruction may cause equipment failure, and it will void the warranty.



NOTICE

When cleaning the surface, do not use any organic solvent such as thinner or benzine. Otherwise, the paint and markings on the surface may get damaged. For cleaning the surface, remove the dust and debris and wipe with a clean dry cloth.



NOTICE

Do not place a container containing liquid on the equipment. The equipment can be damaged if knocked over.

1 Introduction

AlphaMINDS Conning & Docking is a high-end vessel monitoring solution that enables safer and more efficient maritime operations. It consists of:

- an AlphaMINDS Conning application that contains standard presentations for displaying information for assisting in safe navigation of a vessel
- an AlphaMINDS Docking application that contains standard presentations for displaying information for assisting in safe docking of a vessel.

The system can be integrated on new build or retrofit projects or used as standalone system next to existing equipment on board. Standard interfaces and protocols are supported.

2 Intended use



WARNING

AlphaMINDS, which incorporates official data as well as other sources, is designed to facilitate the use of official nautical charts and not to replace them. Only official nautical charts and notices for navigators contain all the information necessary for safe navigation.



WARNING

AlphaMINDS, which incorporates validation of data from other sources, is designed to display AlphaMINDS-specific alerts. AlphaMINDS is no AMS (Alert Management System) and does not replace an AMS!

The system may be used for safer navigation of a vessel and safer docking of a vessel. It does not replace official nautical charts and notices for navigators.

3 General description

3.1 System overview

Figure 1 shows a schematic example of an AlphaMINDS Conning and Docking system. It shows the components and communication between the components.




Figure 1: Schematic example of an AlphaMINDS Conning and Docking setup

NOTE: AlphaMINDS Conning and Docking consists of at least AlphaMINDS Conning and Docking software + AlphaMINDS Computer + AlphaMINDS USB dongle. Other components can vary as the system can be integrated on new build or retrofit projects or used as standalone system next to existing equipment on board.

NOTE: For the AlphaMINDS Docking application, an Alphatron recommended GNSS receiver and antenna is required. More GNSS receivers can be used to provide a more accurate heading, roll & pitch measurements, and redundancy, when required. GNSS receivers and antennas are not required for the AlphaMINDS Conning application.

3.2 Hardware

The hardware consists of an AlphaMINDS computer, an AlphaMINDS USB dongle, a monitor, and optionally; GNSS receiver(s), GNSS antenna(s), and serial to an IP-based Ethernet LAN device server.

3.2.1 AlphaMINDS computer



The AlphaMINDS computer is an IEC90645 certified marine computer.

3.2.2 AlphaMINDS USB dongle



The system requires a AlphaMINDS USB dongle for licensing. AlphaMINDS software will check for the presence of the dongle in the AlphaMINDS computer before running and while running.

3.2.3 Monitor (optional)

AlphaMINDS supports monitors with a resolution of 1920x1200 and 1920x1080.

3.2.4 External devices

Typical external devices connected with AlphaMINDS are GPS, GNSS, compass, ROT sensor, log sensor, TCS, RFU, INS.

3.2.4.1 Serial to an IP-based Ethernet LAN device server

All data must be delivered to the AlphaMINDS computer via a LAN interface.

AlphaMINDS Conning and Docking software can communicate using a wide range of data protocols (e.g. NMEA 0183) and electrical protocols (e.g. RS232, RS422, RS485, and Ethernet).

Serial data (e.g. via RS232, RS422, or RS485) shall be converted to Ethernet data (using TCP/IP or UDP packets). This is possible via a JRC CMH-2370 (SLC) Serial LAN interface circuit, which may be available in a JRC MFD, or one can do this by using a simple and standard Serial to IP converter.

3.2.4.2 GNSS hardware

The AlphaMINDS Docking application requires GPS or GNSS position information. The system can work with a standard GNSS receiver (connected to the LAN network).

A standard GNSS receiver might not suffice when it comes to berthing a vessel (in this case, precise measurement of heading and ROT during low speed are of utmost importance).

For this reason, Alpatron developed the CT-104 GNSS Multi-band GNSS receiver that delivers decimeter level accuracy in seconds (depending on atmospheric and environmental conditions), to be used as part of a fixed installation of the navigation equipment.

Additional GNSS receivers and antennas are optional, but provide for more accurate heading, roll and pitch measurements, and redundancy. To get the best results, the antennas should be installed on the vessel with the greatest possible distance between them.

CT-104 GNSS receiver

The CT-104 GNSS Multi-band GNSS receiver (not type-approved for navigational purpose) is a modular system in terms of the number of units, thus antennas and integrates multi-band GNSS and RTK technology. Depending on the number of these units connected to the Ethernet network, the GNSS receivers will provide data on precise positioning and accurate heading.

The GNSS receiver will by default calculate the position by combining and using the signals from four GNSS constellations available such as GPS, Glonass, BeiDou and Galileo. By using an augmentation system like SBAS correction signals, the positioning will already be a lot more accurate.

The CT-104 GNSS-receiver comes with built-in support for standard RTCM corrections, supporting decimeter-level navigation from local base stations or from VRS in a Network RTK setup. This means that when a more accurate positioning (below 20 cm or cm-level accuracy) is required, one should then activate the integrated RTK receiver with a 3rd party RTK-subscription, which will give an even higher accuracy.

High-Precision RTK GNSS antenna

A High-Precision RTK GNSS Antenna can be connected to the CT-104 GNSS receiver. This seven-frequency survey antenna integrates GPS (L1 & L2) and GLONASS (G1 & G2), Galileo (E1/E5b) and BeiDou (B1 & B2 & B3), which can be widely used in geodetic surveys and thus are ideal for the AlphaMINDS Docking application.

3.3 Software

AlphaMINDS is an Alpatron product for monitoring and/or controlling all kinds of equipment onboard a vessel. AlphaMINDS is also known as a software suite, as it typically is a collection of two or more software applications bundled and sold together. The applications always have a similar theme, and may have correlative features and functionality.

AlphaMINDS Conning & Docking software is an AlphaMINDS product for monitoring (only), to enable safer and more efficient maritime operations. The software consists of:

- an AlphaMINDS Conning application that contains standard presentations for displaying information for assisting in safe navigation of a vessel
- an AlphaMINDS Docking application that contains standard presentations for displaying information for assisting in safe docking of a vessel.



AlphaMINDS is based on the automation and connecting platform **Lynx**, specifically designed by Alpatron Marine as maritime SCADA software for monitoring and controlling all kinds of equipment onboard a vessel.

OpenBridge

Integrated in Lynx is the **OpenBridge** design guideline that will give a better user experience with regards to design, styling and easy recognition of indicators, messages, alarms of the graphical user interface. Consistency across systems is an essential aspect for reducing human errors and this will contribute to an improvement of the quality of vessel bridges, the work environment for seafarers and overall vessel safety.

4 Operation



WARNING

AlphaMINDS, which incorporates official data as well as other sources, is designed to facilitate the use of official nautical charts and not to replace them. Only official nautical charts and notices for navigators contain all the information necessary for safe navigation.



WARNING

AlphaMINDS, which incorporates validation of data from other sources, is designed to display AlphaMINDS-specific alerts. AlphaMINDS is no AMS (Alert Management System) and does not replace an AMS!

AlphaMINDS Conning & Docking provides information for maritime operations. The AlphaMINDS applications, menus, menu items, and widgets are explained in the next sections.

NOTE: Visualization is configured and depends on available data sources and user preferences. Note that all widgets are examples and provided for reference only. Default end-user settings are configured in the Settings (for more information, refer to chapter 6).

NOTE: In the AlphaMINDS Docking application, certain settings can be changed quickly during operation via widgets on the operational page. These specific settings are explained in this chapter.

NOTE: Some widgets shows selectable data sources. They can be selected if multiple sources are configured.

4.1 HMI overview

The AlphaMINDS Conning & Docking applications are shown in Figure 2 and Figure 3.





Figure 2: AlphaMINDS Conning application



Figure 3: AlphaMINDS Docking application

4.1.1 Top bar items

All AlphaMINDS applications have a similar top bar. The top bar contains six five generic items.



Item	Name	Description
1	Menu	This button provides access to various pages (e.g. Settings page and Help & Support page).
2	Breadcrumb	The name of the current (application and) page.
3	Alerts	This button opens the Alerts pop-up. It is highlighted when there is an alert.
4	Display options	This button opens a pop-up that allows a user to change the palette.
5	Application launcher	This button provides access to the Application launcher menu, where the user can select the AlphaMINDS Conning or the Docking application.
6	User options	This button opens a pop-up that allows a user to sign in.

All items are explained in more detail in the subsequent sections.

4.1.1.1 Menu

The information displayed in the menu depends on the AlphaMINDS application. For the AlphaMINDS Conning application, refer to section 4.1.2 on page 26. For the AlphaMINDS Docking application, refer to section 4.1.3 on page 32.

4.1.1.2 Alerts



WARNING

AlphaMINDS, which incorporates validation of data from other sources, is designed to display AlphaMINDS-specific alerts. AlphaMINDS is no AMS (Alert Management System) and does not replace an AMS!

This section explains the Alert page and Alert list page. For troubleshooting, refer to chapter 7 on page 72. For help and support, refer to chapter 8 on page 74.

The Alert button is highlighted (i.e. yellow colored) when an alert is triggered. Press the Alerts button (on the top bar) to open the Alert page. The highlight is removed when all alerts are rectified.




Figure 4: AlphaMINDS Conning application > Alert page

NOTE: The buttons 'Muted' and 'Aked' are disabled/inactive.

NOTE: Alerts are divided in four priorities: emergency alarms, alarms, warnings and cautions. The alerts triggered by and shown in AlphaMINDS are always cautions.

NOTE: The alerts triggered by and shown in AlphaMINDS are not audible.

For more details on an alert, press on the > (chevron right) button.




Figure 5: AlphaMINDS Conning application > Alert page with an unfolded item

For more details on alerts (e.g. priority and state), press on the ⇅ (unfold) button. The Alert list page will be shown.





Figure 6: AlphaMINDS Conning application > Alert list page


4.1.1.3 User options

Item	Description
<div data-bbox="204 371 660 887"> <p>USER</p> <p>Username</p> <p>Password</p> <p>Sign in</p> <hr/> <p>RECENTLY SIGNED IN</p> <p>User1 User2 User3</p> </div> <p data-bbox="204 891 421 922">No user signed in.</p> <div data-bbox="204 958 660 1249"> <p>USER</p> <p>User1</p> <p>Sign out</p> </div> <p data-bbox="204 1254 395 1285">User1 signed in.</p>	<p data-bbox="687 376 1342 479">There are three end-user profiles (User1, User2, and User3) that can sign in via this pop-up. No password is required.</p> <p data-bbox="687 519 1342 586">Each end-user profile has unique pre-defined settings. These settings are loaded when signed in.</p> <p data-bbox="687 627 1378 730">NOTE: Advanced settings and certain general settings are password protected (accessible with administrator credentials). These settings apply to all end-users.</p>

4.1.1.4 Display options

Item	Description
	<p>The palette can be set manually to:</p> <ul style="list-style-type: none"> - Night - Dusk - Day - Bright


4.1.1.5 Application launcher

Item	Description
	<p>The Application launcher shows the available AlphaMINDS applications. Press an icon to start the application.</p>

4.1.2 AlphaMINDS Conning application

4.1.2.1 Overview






The HMI display layout of the AlphaMINDS Conning application consists of four main areas.



Item	Name	Description
1	Top bar	The top bar provides access to the menu, alerts, and various other settings explained in section 4.1.1 on page 21.
2	Left area	The left area shows the widgets TIME & POSITION, COMPASS and METEO.
3	Middle area	The main area shows the widgets ROT and PROPULSION.
4	Right area	The right area shows the widgets VESSEL SPEED, WAYPOINT & AUTO PILOT (shown in Navigation mode) or GROUND SPEED (shown in Docking mode), DEPTH and WATER TRACK.




4.1.2.2 Menu

The menu is used to select to access the Settings, and to view Help & Support information.

Item	Description
	<p>Navigation mode Mode that will show the widgets WAYPOINT & AUTO PILOT, instead of the widget GROUND SPEED (shown in Docking mode)</p>
	<p>Docking mode Mode that will show the widget GROUND SPEED, instead of widgets WAYPOINT & AUTO PILOT (shown in Navigation mode)</p>
	<p>Settings Refer to chapter 6 on page 49.</p>
	<p>Help & Support Provides information on Help & Support. Refer to chapter 7 on page 72.</p>
	<p>Alphatron Marine Provides system information such as software versions.</p>



4.1.2.3 Left area

The left area shows the widgets TIME & POSITION, COMPASS and METEO.

Item	Description
<p>TIME & POSITION</p> 	<p>This widget shows the actual time and position data.</p> <p>The rating derives from the HDOP value. Possible values and ratings are explained in Appendix D.</p>
<p>COMPASS</p> 	<p>This widget shows the following compass data (graphical and numerical):</p> <ul style="list-style-type: none"> - Heading (HDG) - Course Over Ground (COG) - Wind <ul style="list-style-type: none"> ○ Bearing (BRG) ○ Speed (SPD) - Current <ul style="list-style-type: none"> ○ Set ○ Drift
<p>METEO</p> 	<p>This widget shows the following Meteo data:</p> <ul style="list-style-type: none"> - Pressure - Humidity - Air temperature - Water temperature




4.1.2.4 Middle area


The middle area shows the widgets ROT and PROPULSION.

Item	Description
<p>ROT</p> 	<p>This widget shows the ROT data (graphical and numerical).</p> <p>NOTE: The displayed information may vary, depending on Range & Style settings.</p>
<p>PROPULSION</p> 	<p>This widget shows the propulsion data (graphical and/or numerical).</p> <p>NOTE: The displayed information may vary, depending on the target vessel and its equipment.</p>

4.1.2.5 Right area

The right area shows the widgets VESSEL SPEED, AUTO PILOT, DEPTH and TRACK.

Item	Description
<p>VESSEL SPEED</p> 	<p>This widget shows the following vessel movement data (graphical and numerical):</p> <ul style="list-style-type: none"> - Heading - Speed Over Ground (SOG) - Course Over Ground (COG) - Speed Through Water (STW) <p>Other sources can be selected if multiple sources are configured.</p>
<p>WAYPOINT & AUTO PILOT (shown in Navigation mode)</p> 	<p>The WAYPOINT widget shows the following data (graphical and numerical):</p> <ul style="list-style-type: none"> - Waypoint name - Bearing - Distance - Waypoint shape (shows the turn at the next waypoint) <p>The AUTO PILOT widget shows the following data (graphical and numerical):</p> <ul style="list-style-type: none"> - Steering mode - Set HDG - Set ROT - Actual HDG - Actual ROT
<p>GROUND SPEED (shown in Docking mode)</p> 	<p>The GROUND SPEED widget shows the following data (graphical and numerical):</p> <ul style="list-style-type: none"> - Shape (shows the speeds) - Bow - Long - Stern

Item	Description
<p data-bbox="204 286 496 315">DEPTH & WATER TRACK</p> 	<p data-bbox="804 360 1366 461">The DEPTH widget shows the actual depth and logged depth (graphical and numerical). The logged depth can be set to 3, 5, or 10 minutes.</p> <p data-bbox="804 501 1382 674">The TRACK widget shows the total and voyage. Both values are provided by the speed log device. Total is the total cumulative water distance. Voyage is the water distance since last reset (voyage distance could be reset each trip).</p>

4.1.3 AlphaMINDS Docking application

The AlphaMINDS Docking application implements full support for AIS. The AIS functionality includes receiving and viewing AIS data, displaying AIS targets in the chart, alerting the mariner to potentially dangerous AIS targets as well as to the loss of communication with targets.

4.1.3.1 Overview

The HMI display layout of the AlphaMINDS Docking application consists of five main areas.




Item	Name	Description
1	Top bar	The top bar provides access to the menu, alerts, and various other settings explained in section 4.1.1 on page 21.
2	Left area	The left area shows vessel navigation data.
3	Main area	The main area shows the chart.
4	Right area	The right area shows chart options and vessel propulsion data.
5	Bottom bar	The bottom area shows scale and orientation options.

Area's can be adjusted using the buttons $\left| \right\rangle$ (expand left), $\left| \leftarrow$ (expand right), $\left| \right|$ (minimize right), $\left| \leftarrow$ (minimize left), $\hat{\vee}$ (unfold), and \times (fold).

4.1.3.2 Menu

The menu is used to select a Docking mode, to access the Settings, and to view Help & Support information.

Item	Description
	<p>Automatic Mode In 'Automatic Mode', either 'Docking Mode', 'Harbor Mode', or 'Voyage Mode' is selected automatically based on vessel speed. 'Lock Approach Mode' is not selected automatically, and can be selected only manually.</p> <p>'Docking Mode' will be selected automatically if the vessel speed is <2 m/s. 'Harbor Mode' will be selected automatically if the vessel speed is between 2 and 5 m/s. 'Voyage Mode' will be selected automatically if the vessel speed is > 5 m/s. When switching from one mode to another, the chart automatically zooms in/out and adds/removes information as predefined for each mode.</p> <p>Docking Mode Provides additional information such as position prediction vessel (used during docking to see if the vessel is properly steered and aligned), speed and distance information (used during docking to see the distance between the vessel and objects). Scale typically 1:2000, but can be adjusted by end-user.</p> <p>Harbor Mode Provides additional information such as position prediction lines. Scale typically 1:5000, but can be adjusted by end-user.</p> <p>Voyage Mode Provides information during normal navigation or sailing such as an zoomed-out chart for overview situations. Scale typically 1:10000, but can be adjusted by end-user.</p> <p>Lock Approach Mode Provides additional information such as alignment lines (two lines straight ahead and in line with the vessel) that can be used, for example, when approaching a lock or narrow channel to see if the vessel is straight ahead and properly aligned. Scale typically 1:200, but can be adjusted by end-user.</p> <p>For examples and more information on the modes, refer to section 4.1.3.4 on page 36.</p>


Item	Description
	<p>Settings Refer to chapter 6 on page 49.</p> <p>Help & Support Provides information on Help & Support. Refer to chapter 7 on page 72.</p> <p>Alphatron Marine Provides system information such as software version.</p>

4.1.3.3 Left area

The left area shows ROT, HEADING & COG, and SPEED widgets.

NOTE: Visualization of the widgets can be altered (refer to chapter 'Settings').

Item	Description
<p>ROT</p>	<p>This widget shows the actual ROT (graphical and numerical).</p>
<p>HEADING & COG</p>	<p>This widget shows the heading and COG (graphical and numerical).</p>

Item	Description
<p data-bbox="201 286 284 315">SPEED</p>  <p data-bbox="236 840 560 1003"> Bow -0.1kn Forward 7.2kn Stern -0.4kn </p>	<p data-bbox="687 353 1358 427">This widget shows the multi-directional actual speed of the vessel (graphical and numerical)..</p> <p data-bbox="687 465 1374 539">Bow and stern speed is negative when in the direction of port and positive when in the direction of starboard.</p> <p data-bbox="687 577 1374 651">The speeds are calculated using heading, ROT, SOG, COG, and GPS sensor position.</p>

4.1.3.4 Main area

The main area shows the chart and additional chart layers.

The chart orientation and chart scale can be set via the buttons on the bottom bar (see section 4.1.3.6 on page 45). The visibility of chart layers can be changed via the Layers widget during operation (see section 4.1.3.5 on page 42).

The following chart layers are available and can be shown in the main area:

- **Alignment lines;** a layer that shows two lines straight ahead and in line with the vessel. It can be used, for example, when approaching a lock or narrow channel to see if the vessel is straight ahead and properly aligned. See Figure 8 for an example.
- **Position prediction vessels;** a layer that shows one or more scale models of the vessel at a predicted position. It can be used during Docking to see if the vessel is properly steered and aligned. It can also be used during turns for obstacle avoidance. See Figure 7 for an example.
- **Position prediction lines;** a layer that shows four lines (one from each 'corner' of the vessel) to indicate the predicted vessel position. It can be used in Harbor conditions to see if the vessel is properly steered and aligned. See Figure 9 for an example.
- **Speed information;** a layer that shows speed info on top of the vessel. It is typically used during Docking or Lock Approach to see if the vessel is properly controlled. See Figure 7 for an example.
- **Distance information;** a layer that shows the distance from vessels' hull to the quay (or other objects in the chart) as reference into the current chart will also be presented. See Figure 7 as an example.
- **Route information;** a layer that shows the route (received from ECDIS). See Figure 11 for an example. NOTE: Route information is not related to the modes as shown in Table 1.

Table 1 shows the available modes and their default layers.

Mode	Included in Automatic mode	Layer				
		Position Prediction Vessel	Position Prediction Lines	Alignment Lines	Speed Information	Distance Information
Automatic	-	-	-	-	-	-
Docking	✓	✓			✓	✓
Lock Approach				✓	✓	✓
Harbor	✓		✓			
Voyage	✓					

Table 1: Modes and their layers

The default chart orientation, default chart scale and default chart layers can be configured in the Chart Settings (refer to section 6.9 on page 70).

Chart examples

The next pages show examples of chart layers.

NOTE: Figure 7, Figure 9, and Figure 10 show Automatic mode in the top bar (as selected by the user), however a specific mode is selected by the system. This can be recognized by the scale of the chart and visibility of the layers.

NOTE: The chart shows additional information by default (e.g. the latitude scale, north arrow, and 'm' for - the unit of measure - for depth). This can be changed at 'Chart Settings > Display Settings > Viewing Groups'.




Figure 7: AlphaMINDS Docking application > Main area > Docking mode example

Figure 7 shows the following layers: (1) Position prediction vessel, (2) Speed information, and (3) Distance information.




Figure 8: AlphaMINDS Docking application > Main area > Lock Approach mode example

Figure 8 shows the following layers: (1) Alignment lines, (2) Speed information and (3) Distance information.




Figure 9: AlphaMINDS Docking application > Main area > Harbor mode example

Figure 9 shows the following layer: (1) Position prediction lines.




Figure 10: AlphaMINDS Docking application > Main area > Voyage mode example with no layers

Figure 10 shows no layers.







Figure 11: AlphaMINDS Docking application > Main area > Automatic mode example with route information

Figure 11 shows the following layer: (1) Route information.

4.1.3.5 Right area

The right area shows a LAYERS and PROPULSION widgets. The LAYERS widget is used to hide or display information on the chart.


Item	Description
<p>LAYERS - POSITION PREDICTION</p> 	<p>Show Vessel (i.e. one or more scale models of the vessel at a predicted position):</p> <ul style="list-style-type: none"> - Auto (position prediction vessel will be shown when in Docking mode (see Figure 7 on page 37)) - On - Off <p>Show Lines (i.e. two lines that show the predicted vessel position):</p> <ul style="list-style-type: none"> - Auto (position prediction lines will be shown when in Harbor mode (see Figure 9 on page 39)) - On - Off <p>NOTE: Visualization can be altered (refer to chapter 'Settings').</p>
<p>LAYERS – ALIGNMENT LINES</p> 	<p>Show Lines:</p> <ul style="list-style-type: none"> - Auto (alignment lines will be shown when in Lock Approach mode (see Figure 8 on page 38)) - On - Off

Item	Description
<p>LAYERS – SPEED INFO</p> 	<p>Show Speed:</p> <ul style="list-style-type: none"> - Auto (speed info will be shown (on the vessel) when in Docking mode (see Figure 7 on page 37) or Lock Approach mode) - On - Off
<p>LAYERS – DISTANCE INFO</p> 	<p>Show Distance:</p> <ul style="list-style-type: none"> - Auto (distance info will be shown (on the chart) when in Docking mode (see Figure 7 on page 37) or Lock Approach mode) - On - Off

Item	Description
<p>PROPULSION</p> <p>PROPULSION</p> <p>BOW THRUSTERS Power 34.3%</p> <p>BOW AZIMUTH THRUSTERS</p> <p>Direction 39.3° Power -3.3%</p> <p>Direction -91.5° Power -59.6%</p> <p>MAIN ENGINES</p> <p>Engine Spd. -999rpm Engine Spd. 627rpm</p> <p>Shaft Spd. -98.0% Prop. Pitch -55.3°</p> <p>RUDDERS</p> <p>Angle -35.0°</p> <p>STERN AZIMUTH THRUSTERS</p> <p>Direction 157.7° Power -93.5%</p> <p>Direction 71.2° Power -93.5%</p> <p>STERN THRUSTERS Power 43.2%</p>	<p>This widget shows the propulsion data (graphical and/or numerical).</p> <p>NOTE: The displayed information may vary, depending on the target vessel and its equipment.</p>

4.1.3.6 Bottom bar

The bottom bar shows chart scale and orientation options.



No	Item	Description
1	Auto Scale	Button to enable or disable 'Auto Scale'. Enable 'Auto Scale' to scale automatically to the appropriate zoom level for the active mode.
2	Scale	Buttons and input field to change the scale.
3	North up	Button to set chart orientation to north up.
4	Head up	Button to set chart orientation to head up.

NOTE: 'Course up' is not supported.

5 Installation

This chapter describes the installation of the AlphaMINDS Conning and Docking system.

The system is easy to install and maintain on the vessel. Normally it is installed in the wheelhouse or in the bridge.

5.1 Initial inspection

The AlphaMINDS computer shall be inspected before installation as described in this section.

Inspect the shipping cartons - of each component - immediately upon receipt for evidence of damage during the transport. If the shipping carton is severely damaged or water stained, request the carrier's agent to be present when opening the carton. Save the carton and packing material for future use.



CAUTION

To avoid hazardous electric shock, do not perform electrical tests if there is any sign of shipping damage to the AlphaMINDS computer.

Check that the contents of the shipment are as listed in the enclosed packing list. If the contents are incomplete, if there is mechanical damage or defect, or if the system does not work properly, notify your dealer.

After you unpack the system do as follows:

- Inspect each component thoroughly for hidden damaged or loose components or fittings.
- Check for loose or missing hardware.
- Fasten any loose hardware.

5.2 Installing the system



NOTICE

The AlphaMINDS computer must be installed in accordance with the installation methods described in the manual of the computer. Acting otherwise will void the warranty.

The AlphaMINDS systems can be integrated with the vessels existing installation or can be installed as a standalone system. Refer to the project specifications and installation drawings for the details.

For information on cables and wiring of the system, refer to section 5.2.4 on page 47. For information, on how-to configure the system, refer to section 5.3 on page 47.

5.2.1 General installation requirements

All components in the system must be placed indoors! For information on environmental requirements, refer to the technical specifications.

5.2.2 Power requirements

The AlphaMINDS computer operates on 100 – 240 Vac and 24 Vdc (nominal value).

NOTE: The computer has a dual input power supply which will accept both AC and DC input. If both inputs are connected, the unit will be powered by AC. If AC is disconnected it will automatically switch over to DC without affecting the operation of the unit. This makes it possible to use AC power as primary power and a 24V battery as secondary power, eliminating the need for expensive UPS systems.

5.2.3 Grounding availability

**NOTICE**

Propagation and reception of electromagnetic energy may cause unwanted effects such as electromagnetic interference (EMI) or even physical damage in operational equipment.

Use a suitable location for connecting the computer to vessel ground (hull). The computer has a grounding screw. Connect the grounding bolt to the vessel's ground with a low impedance connection.

Grounding aims to reduce emissions or divert EMI.

5.2.4 Connecting the system

Electrical installation of the components shall be performed according to the project specifications and installation drawings (cable diagrams and connection diagrams).

Note that cables are typically installed, finished, and connected by an electrical subcontractor.

5.3 Commissioning and testing

NOTE: A soft-reset is not available, use the hard-reset switch on the AlphaMINDS computer.

This section provides the information required for commissioning and testing of the system. Commissioning and testing include setting various parameters, and performing functional checks of the equipment.

Preparation

1. Before starting with commissioning and testing:
 - a) Get the information needed to configure the system.
 - b) Get the correct documentation (including but not limited to; cable diagrams and connection diagrams)
 - c) Get a good understanding of the system.
 - d) Verify that the cables are prepared/installed as required per project specifications
 - e) Verify that the computer is connected according to the User Manual of the computer.
 - f) Verify availability of power supply.
2. Before power on, verify that the following conditions are met:
 - a) All components of the system available and installed correctly.
 - b) All components of the system are secured.
 - c) Power and data connections checked.
 - d) Cables are secured and undamaged.

- e) CAN bus network topology and terminations checked, if applicable.
- f) Shielding is connected in accordance with wiring instructions and sleeved where required.

Initial setup and dock trial

- 3. Power on the system.
- 4. Set all the necessary parameters of the vessel and sensor interface data, see chapter 6 Settings on page 49.
- 5. Check availability of data coming from equipment and sensors (e.g. Gyro, Compasses, GPS, ECDIS).
- 6. Verify correct functioning of the following:
 - a) Rudder position feedback
 - b) Navigation data (present)
 - c) Alerts (no alerts at this stage)
- 7. Backup the settings. The settings are stored as CFG files at 'C:\Alphatron\AlphaMINDS' (folder 'SystemConfiguration' and 'UserSettings').

NOTE: In order to restore the settings, the AlphaMINDS must be closed first!

Sea trial

- 8. Verify correct functioning of the following:
 - a) Rudder position feedback
 - b) Navigation data (present)
 - c) Alerts (no alerts at this stage)
- 9. Verify correct functioning of the AlphaMINDS Conning application.
- 10. Verify correct functioning of the AlphaMINDS Docking application, if applicable.
- 11. Backup the settings.

6 Settings

This chapter provides an overview and description of all settings (for end-user and administrator).

Settings are grouped and depend on user credentials and available applications.




Figure 12: Setting pages (signed in as end-user and both applications available)




Figure 13: Setting pages (signed in as administrator and both applications available)

No	Item	Remarks
1	Units	This page is used to configure settings of units (e.g. for distance, speed, temperature, pressure)
2	Range & Style	This page is used to configure settings of range and style (e.g. for depth, rudder, ROT)
3	AIS	This page is used to configure settings of AIS features, AIS filters, and AIS settings. NOTE: AIS settings are shown only when signed in as administrator!

No	Item	Remarks
4	Sensor Settings	This page is used to configure settings of connected sensors. NOTE: Shown only when signed in as administrator.
5	Vessel Settings	This page is used to configure settings of the vessel. NOTE: Shown only when signed in as administrator.
6	System Settings	This page is used to configure App and display settings. NOTE: Shown only when signed in as administrator.
7	Network Settings	This page is used to configure settings such as UDP and Modbus setting.
8	Docking Settings	This page is used to configure settings such as prediction time, prediction vessel, and distance detection. NOTE: Shown only when the AlphaMINDS Docking application is installed.
9	Chart Settings	This page is used to configure settings chart settings. This page is also used to add/remove charts. NOTE: Shown only when the AlphaMINDS Docking application is installed.

When displayed on a settings page, the settings can be reset to default values via a slider button. Slide the button to the right, until a checkmark appears, and release it to reset to default values.




Figure 14: Reset to default settings (slider button)

The next subsections will explain the settings in more detail. Self-explanatory settings have a '-' at the description.

6.1 Units

This page is used to configure settings of units (e.g. for distance, speed, temperature, pressure).




Figure 15: AlphaMINDS > Settings > Units > Distance

Setting	Value	Description
Distance		
Depth	m or ft	-
Distance Sensor	cm, m or ft	-
Pitch/Angle		
Propeller pitch angle	° or %	-
Thruster pitch angle	° or %	-
Rudder angle	° or %	-
Pressure		
Air Pressure	hPa or mbar	-
Rotation Speed		
Shaft rotation speed	rpm, 1/min, 1/s, or %	-
Thruster rotation speed	rpm, min-1, s-1, or %	-
Speed		
Vessel speed	cm/s, m/s, km/h, or kn	-
Current drift	m/s, km/h, or kn	-
Wind speed	m/s, km/h, or kn	-
Temperature		
Air temperature	°C or °F	-
Water temperature	°C or °F	-

6.2 Range & Style

This page is used to configure settings of range and style (e.g. for depth, rudder, ROT).

Setting	Value	Description
Depth		
Depth visible range	50, 100, 200, or 500	The scale in the current selected unit. It is not scaled when switching units.
Depth timeline [min]	3, 5, or 10	Depth visible time. NOTE: Depth logging time is 10 minutes.
ROT		
ROT [°/min]	40, 80, 120, 160 or 200	-
ROT style	Regular, PortStarboard, or Bar	Option 'PortStarboard' shows a red and green line.
Rudder		
Rudder angle [°]	45, 60, or 90	-
Rudder style	Regular or PortStarboard	-

6.3 AIS

This page is used to configure settings of AIS features, AIS filters, and AIS settings.

6.3.1 Features

Setting	Value	Description
AIS Visibility		
Show targets	On or Off	Show targets (as symbols) indicating the presence and orientation of vessels equipped with AIS in a certain location.
Range Marks		
Visibility range mark	On or Off	When a target is inside this range, it is displayed in the chart. Targets outside the range are not displayed.
Activation range mark	On or Off	When a target is inside this range, the target symbol changes and additional information about the target appears in the chart view (name, COG, SOG).
Danger range mark	On or Off	When a target is inside this range, the target symbol turns red.
Target Features		
Show target outline	On or Off	AIS targets can be displayed as true scale symbols based on dimensions from the AIS messages.
Show heading line	On or Off	To show the heading of an AIS target, heading line is used.
Show turn indicator	On or Off	To show that an AIS target is turning, the turn indicator is used (pointing in the direction of the turn).
Show velocity vector	On or Off	Velocity vector of an AIS target is a vector predicting position of the target in a specified period of time based on the current speed and course. The target's speed and course over ground (SOG and COG) are used.
Velocity vector length [s]	10 – 360	Length of the velocity vector.
Show velocity vector time increments	On or Off	Display time marks on the velocity vector.

Setting	Value	Description
Velocity vector time increments step size [s]	10 – 360	Time mark step for the velocity vector.
Show relative velocity vector	On or Off	-
Show path predictor	On or Off	Display a path prediction vector (or path predictor) (along with the velocity vector). It is based on SOG, COG and ROT.
Show past track	On or Off	To monitor track of AIS targets over time.
Past track interval [s]	10 – 360	Interval (step of time marks) of the past track.
Past track length [s]	10 – 360	Length of the past track.
Show target label	On or Off	Show the name (or MMSI when the name is not available) of activated targets
Show target data	On or Off	-
Highlight targets	On or Off	Show the highlighted variant of targets (filled in vessel or triangle)

6.3.2 Filters

Setting	Value	Description
Target Filtering		
Enable filtering	On or Off	Main setting that enables or disables all filters mentioned below
Type Filtering		
Show base stations	On or Off	-
Show SAR aircrafts	On or Off	-
Show SARTs	On or Off	-
Show real AToNs	On or Off	-
Show virtual AToNs	On or Off	-
Show ASM objects	On or Off	-
Show sleeping targets	On or Off	-
Show activated targets	On or Off	-
Show class A targets	On or Off	-
Show class B targets	On or Off	-
Value Filtering		
CPA filter enabled	On or Off	-
CPA filter distance [m]	50 – 1000	-
TCPA filter enabled	On or Off	-
TCPA filter time [s]	10 – 360	-
Distance filter enabled	On or Off	-

Setting	Value	Description
Distance filter [m]	1000 – 20000	-
Speed filter enabled	On or Off	-
Speed filter [m/s]	0.1 – 10.0	-

6.3.3 Settings

Setting	Value	Description
Past Track		
Past track to store [s]	10 – 360	-
CPA Settings		
Calculate CPA	On or Off	-
Danger CPA [m]	10 – 1000	-
Danger TCPA [s]	0 – 600	-
Visibility Settings		
Visibility range enabled	On or Off	-
Visibility distance [m]	1000 – 100000	-
Activation Settings		
Auto activation enabled	On or Off	-
Activation distance [m]	1000 – 100000	-
Danger Distance Settings		
Danger distance alert enabled	On or Off	-
Danger distance [m]	1000 – 100000	Distance of the Danger Range Mark. See also Danger Range Mark at 'AIS - Filters'
Target Lost Settings		
Remove vessel timeout [s]	10 – 360 s	-
AToN Settings		
Show real AToN purpose	On or Off	-
AToN from edition one	On or Off	-

6.4 Sensor Settings

NOTE: These settings are password protected (accessible with administrator credentials).

This page is used to configure settings of connected sensors (e.g. GPS, compass). These setting can be used by all AlphaMINDS applications.

6.4.1 AIS

Setting	Value	Description
AIS 1..2		
Enabled	On or Off	Setup of channel for data input. - On: Sensor connected - Off: Sensor not connected
Source	61162-1/2 or 61162-450	Setup IEC 61162-1/2 for single talker and multiple listeners, or setup IEC 61162-450 for multiple talkers and multiple listeners (Ethernet interconnection).
NMEA UDP device	[value]	Setup NMAE UDP device. Editable when 61162-1/2 is selected.
NMAE 450 channel	[value]	Setup NMAE 450 device. Editable when 61162-450 is selected.
SFI	[value]	Setup SFI (System Function Identifier). Editable when 61162-450 is selected.

6.4.2 Anemometer

Setting	Value	Description
Anemometer 1..2		
Settings identical to AIS	-	-

6.4.3 Auto Pilot

Setting	Value	Description
Auto Pilot 1..2		
Settings identical to AIS	-	-

6.4.4 Bow Thruster

Setting	Value	Description
Bow Thruster 1..2		
Enabled	On or Off	Setup of channel for data input. - On: Sensor connected

Setting	Value	Description
		- Off: Sensor not connected
Source	61162-1/2 or 61162-450 or Modbus	Setup IEC 61162-1/2 for single talker and multiple listeners, setup IEC 61162-450 for multiple talkers and multiple listeners (Ethernet interconnection) or setup Modbus communication.
NMEA UDP device	[value]	Setup NMAE UDP device. Editable when 61162-1/2 is selected.
NMEA 450 channel	[value]	Setup NMAE 450 device. Editable when 61162-450 is selected.
SFI	[value]	Setup SFI (System Function Identifier). Editable when 61162-450 is selected.
NMEA source	TRD or XDR	Select NMEA identifier. Editable when 61162-1/2 is selected.
TRD thruster index	[value]	Setup NMEA TRD thruster index number. Editable when 61162-1/2 is selected, in combination with TRD as NMEA source.
XDR RPM identifier	[value]	Setup NMEA RPM identifier number. Editable when 61162-1/2 is selected, in combination with XDR as NMEA source.
MODBUS device	Device 1, Device 2, Device 3 or Device 4	Setup MODBUS device. Editable when Modbus is selected.
MODBUS register type	Coils, inputs, input registers or holding registers	Setup the register type. Editable when Modbus is selected.
RPM register	[value]	Setup the register index number. Editable when Modbus is selected.
RPM table	[value]	Setup the conversion table to go from Modbus register range to displayed range. Editable when Modbus is selected.
Load register	[value]	Setup the register index number. Editable when Modbus is selected.

Setting	Value	Description
Load table	[value]	Setup the conversion table to go from Modbus register range to displayed range. Editable when Modbus is selected.
RPM to load table	<RPM start value>,0;<RPM end value>,100;*	Setup the conversion table to go from RPM value to load percentage. This is only used when the selected display UoM is not available.
Load to RPM table	0,<RPM start value>;100,<RPM end value>;*	Setup the conversion table to go from Load percentage to RPM value. This is only used when the selected display UoM is not available.

* The values must be formatted correctly (i.e. '<X1>,<Y1>;<X2>,<Y2>;... <Xn>,<Yn>'), and must contain at least two sets of points. For example, '0,-90;65535,90' will map a Modbus register range to '[-90, 90]'.

6.4.5 Climate meter

Setting	Value	Description
Climate meter 1..2		
Settings identical to AIS	-	-

6.4.6 Distance Above Water

Setting	Value	Description
Distance Sensor Forward / Starboard Bow / Starboard Stern / Portside Stern / Portside Bow		
Enabled	On or Off	-
Maximum Range [m]		-
Source	61162-1/2 or 61162-450 or Modbus	-
UDP Port		-
SFI		Setup SFI (System Function Identifier). Editable when 61162-450 is selected.
Modbus Register		-
Sensor Minimum Input Range [m]		-
Sensor Maximum Input Range [m]		-

6.4.7 Distance Below Water

Setting	Value	Description
Settings identical to Distance Above Water		-

6.4.8 ECDIS

Setting	Value	Description
ECDIS 1..2		
Settings identical to AIS	-	-

6.4.9 Echo Sounder

uSetting	Value	Description
Echo Sounder 1..2		
Settings identical to AIS	-	-

6.4.10 Engine & Shaft

Setting	Value	Description
Engine 1..2		
Enabled	On or Off	-
Source	61162-1/2 or 61162-450 or Modbus	-
NMEA UDP Device		-
NMEA 450 Channel		-
SFI		Setup SFI (System Function Identifier). Editable when 61162-450 is selected.
NMEA Source		-
RPM Engine Index		-
XDR RPM Engine Identifier		-
XDR RPM Shaft Identifier		-
XDR Angle Propeller Identifier		-
MODBUS Device		-
MODBUS Register Type		-
Engine RPM Register		-
Engine RPM Table		-
Engine Load Register		-
Engine Load Table		-
Shaft RPM Register		-
Shaft RPM Table		-
Shaft Load Register		-
Shaft Load Table		-
Propeller Pitch Angle Register		-
Propeller Pitch Angle Table		-
Propeller Pitch Percent Register		-
Propeller Pitch Percent Table		-

6.4.11 GPS

Setting	Value	Description
GPS1..2		
Settings identical to AIS	-	-

6.4.12 GPS Compass

Setting	Value	Description
GPS Compass 1..2		
Settings identical to AIS	-	-

6.4.13 Gyro Compass

Setting	Value	Description
Gyro Compass 1..2		
Settings identical to AIS	-	-

6.4.14 Magnetic Compass

Setting	Value	Description
Magnetic Compass 1..2		
Settings identical to AIS	-	-

6.4.15 Rudder

Setting	Value	Description
Rudder 1..2		
Enabled	On or Off	Setup of channel for data input. - On: Sensor connected. - Off: Sensor not connected.
Source	61162-1/2 or 61162-450 or Modbus	Setup IEC 61162-1/2 for single talker and multiple listeners, or setup IEC 61162-450 for multiple talkers and multiple listeners (Ethernet interconnection).
NMEA UDP Device		-
NMEA 450 Channel		-
SFI		Setup SFI (System Function Identifier). Editable when 61162-450 is selected.
NMEA Source		-
RSA Rudder Index		-
RSA Angle Scale Factor		-
XDR Angle Identifier		-
MODBUS Device		-

Setting	Value	Description
MODBUS Register Type		-
Angle Register		-
Angle Table		-
Direction Percent Register		-
Direction Percent Table		-

6.4.16 Speed Log

Setting	Value	Description
Speed Log 1..2		
Settings identical to AIS	-	-

6.4.17 Stern Thruster

Setting	Value	Description
Stern Thruster 1..2		
Settings identical to Bow Thruster 1	-	-

6.4.18 Turn Indicator

Setting	Value	Description
ROT Indicator 1..2		
Settings identical to AIS	-	-

6.4.19 Vessel Clock

Setting	Value	Description
Vessel Clock 1..2		
Settings identical to AIS	-	-

6.5 Vessel Settings

NOTE: These settings are password protected (accessible with administrator credentials).

This page is used to configure settings of the vessel. These setting can be used by all AlphaMINDS applications.




Figure 16: AlphaMINDS > Settings > Vessel Settings

6.5.1 Vessel Info




Figure 17: AlphaMINDS > Settings > Vessel Settings > Vessel Info

NOTE: The required values should derive from the Vessel General Arrangement plan.

Setting	Value	Description
Dimensions		
Length [m]	[value]	Length Overall (LOA)
Width [m]	[value]	Breadth Overall (BOA)
Info		
Name	[value]	Name of the vessel
MMSI	[value]	MMSI of the vessel

6.5.2 CCRP Position

Setting	Value	Description
CCRP 1		
X [m]	[value]	Position from vessel centerline to Forward or Aft.
Y [m]	[value]	Position from vessel centerline to Port or Starboard direction.

6.5.3 GPS Position

Setting	Value	Description
GPS 1..2		
X [m]	[value]	Position from vessel centerline to Forward or Aft.
Y [m]	[value]	Position from vessel centerline to Port or Starboard direction.

6.5.4 GPS Compass Position

Setting	Value	Description
GPS Compass 1..2		
X [m]	[value]	Distance in the transversal (Port/Starboard) direction.
Y [m]	[value]	Distance in the longitudinal (Fore) direction, measure from the rear (Aft) of the vessel.

6.5.5 Distance Sensor Position

Setting	Value	Description
Distance Sensor Forward / Starboard Bow / Starboard Stern / Backward / Portside Stern / Portside Bow		
X [m]	[value]	Distance in the transversal (Port/Starboard) direction.
Y [m]	[value]	Distance in the longitudinal (Fore) direction, measure from the rear (Aft) of the vessel.
Direction [°]	[value]	Direction of the sensor.

6.6 System Settings

NOTE: These settings are password protected (accessible with administrator credentials).

This page is used to configure settings of AlphaMINDS system. These setting can be used by all AlphaMINDS applications.




Figure 18: AlphaMINDS > Settings > System Settings

6.6.1 Apps

Setting	Value	Description
Available Apps		
Conning	On or Off	-
Docking	On or Off	-
Default Apps		
Start-up screen	SplashScreen, Conning, Docking	-

6.6.2 Display

Setting	Value	Description
Scale and layout		
Configuration resolution	'1920 x 1080' or '1920 x 1200'	-

6.7 Network Settings

UDP

Setting	Value	Description
UDP Device 1..16		
Enabled	On or Off	-
Port	[value]	-

UDP Multicast

Setting	Value	Description
Transmission Groups		
MISC enabled	On or Off	-
TGTD enabled	On or Off	-
SATD enabled	On or Off	-
NAVD enabled	On or Off	-
VDRD enabled	On or Off	-
RCOM enabled	On or Off	-
TIME enabled	On or Off	-
PROP enabled	On or Off	-

Modbus

Setting	Value	Description
Modbus TCP Device 1..4		
IP address		-
Port		-
Poll group 1 enabled		Enable/disable the polling of an address range. Polling is the action of requesting the data on those addresses. The Modbus device only sends data upon request.
Start address		The address of the first item to poll
Number of coils/registers		Number of coils/registers to poll
Type	coils, inputs, input registers, or holding registers	Coils and inputs are single bits, input registers and holding registers are 16-bit units (hence the 65535 max. value), and one of each is read only. The selected datatype is another address range in the Modbus device.
Poll group 2	Ditto Poll group 1	-

Setting	Value	Description
Poll group 3	Ditto Poll group 1	-
Poll group 4	Ditto Poll group 1	-

6.8 Docking Settings

Predictor

Setting	Value	Description
Predictor Settings		
Prediction time [s]	10 – 360	-
Ghost Vessel Settings		
Visualisation	Outline or Filled	-
Number of vessels	1 - 10	-

Distance Detection

Setting	Value	Description
Distance Detection Settings		
Detection angle [°]	10 – 170	-
Detection range [m]	10 – 1000	-
Detectable Features		
Beacon, cardinal	Enabled or Disabled	-
Beacon, isolated danger	Enabled or Disabled	-
Beacon, lateral	Enabled or Disabled	-
Beacon, safe water	Enabled or Disabled	-
Beacon, special purpose/general	Enabled or Disabled	-
Bridge	Enabled or Disabled	-
Buoy, cardinal	Enabled or Disabled	-
Buoy, installation	Enabled or Disabled	-
Buoy, isolated danger	Enabled or Disabled	-
Buoy, lateral	Enabled or Disabled	-
Buoy, safe water	Enabled or Disabled	-
Buoy, special purpose/general	Enabled or Disabled	-
Coastline	Enabled or Disabled	-
Dam	Enabled or Disabled	-
Daymark	Enabled or Disabled	-
Fence/wall	Enabled or Disabled	-
Gate	Enabled or Disabled	-
Hulk	Enabled or Disabled	-
Land area	Enabled or Disabled	-
Landmark	Enabled or Disabled	-
Light	Enabled or Disabled	-
Light float	Enabled or Disabled	-
Light vessel	Enabled or Disabled	-
Mooring/Warping facility	Enabled or Disabled	-
Obstruction	Enabled or Disabled	-
Offshore platform	Enabled or Disabled	-
Pile	Enabled or Disabled	-

Setting	Value	Description
Pontoon	Enabled or Disabled	-
Pylon/bridge support	Enabled or Disabled	-
Shoreline construction	Enabled or Disabled	-

6.9 Chart Settings

Display Settings

Setting	Value	Description
Chart Settings		
Auto scale	On or Off	Default value is 'Enabled'. If 'Disabled', the pre-set chart scale (see below) will be used.
Chart scale	1:x	Default value is '1:3000'.
Auto scale docking	1:x	Default value is '1:2000'.
Auto scale harbor	1:x	Default value is '1:5000'.
Auto scale voyage	1:x	Default value is '1:10000'.
Auto scale lock	1:x	Default value is '1:2000'.
Orientation	North Up or Heading Up	-
Chart Layers		
Prediction vessels	Auto, On, or Off	Default value is 'Auto' (i.e. automatic chart layer selection based on active mode), also called mode dependent. 'On' and 'Off' are both mode independent.
Prediction lines	Auto, On, or Off	Ditto Prediction vessels
Alignment lines	Auto, On, or Off	Ditto Prediction vessels
Speed info	Auto, On, or Off	Ditto Prediction vessels
Distance sensors	Auto, On, or Off	Show the values measured by the distance sensor, if enabled in the settings menu, otherwise the distance measured/calculated from chart data is shown. Default value is 'Auto'.
Display mode	Base, Standard, Full, Custom	Selecting one of these modes will apply a preset selection to the viewing groups. Default value is 'Standard'.
Viewing groups		The layers that make up the default chart.

Chart Library

Setting	Value	Description
Available charts		
CHART1	Enabled or Disabled	A chart for testing purpose. Default value is 'Disabled'.
NLD	Enabled or Disabled	Default value is 'Enabled'.
OVERVIEW	Enabled or Disabled	A very basic world chart with not much details.

Setting	Value	Description
		Default value is 'Enabled'.
TDS	Enabled or Disabled	Default value is 'Disabled'.

Chart Importer

Setting	Value	Description
Importer		
Chart name	Text	The visible name in the chart library. User must enter a name. The name will be visible in other parts of the application. NOTE: If a name is used that already in use the chart will be updated.
Source drive	Path	The drive that contains the source data. This can be network drives as well. When a drive is selected the drive is scanned for available source data.
Source location	Path	Select the correct source data and use the slider button to import it. NOTE: S-57 charts can be imported if they have a catalog.031 file.

NOTE: Navtor does not supply any nautical charts for inland waterways. For Dutch waterways, freely available charts can be downloaded at vaarweginformatie.nl.

Chart Remover

Setting	Value	Description
Remove Chart		
Chart to remove	Available charts	Select a chart and use the Slider button to remove the chart.

7 Troubleshooting

When an abnormal condition has arisen, an alert message is displayed. For information on how to view the alerts (on the Alert page and Alert list page), see section 4.1.1.2 on page 22.

All alerts are listed in Appendix C: AlphaMINDS alerts.

7.1 Mitigation

Most issues can be mitigated as follows:

1. Check the alert message.
2. Check if the related equipment is switched on.
3. Check the wiring.
4. Check if the related equipment is sending correct data. See section 0 on page 73.

7.2 Support page

The support page contains an overview of one or more Support pages (for end-user and administrator).




Figure 19: AlphaMINDS > Help & Support

8 Help & Support

If the equipment for some reason does not work as described in this manual, contact the distributor or dealer, from where the equipment was originally bought. The distributor or dealer will have experience and know-how to assist with further technical support and troubleshooting.

All information that will get back to Alpatron Marine, either directly or indirectly, will be handled with confidentiality. End-user sensitive data will not be shared with any third party without prior written acceptance from the involved parties.

Appendices

Appendix A: Specifications

Box Contents upon Delivery	Display Requirements	
AlphaMINDS Conning and Docking (includes Conning + Docking software + AlphaMINDS Computer + AlphaMINDS USB dongle (G-009374))	Resolution	1920x1200 or 1920x1080
	Orientation	Horizontal

Physical Dimensions Maritime Computer		Input/Output Signals	
Dimensions (WxHxD)	222x89x300 mm (8.66x3.50x11.81")	DVI-I	1x
Weight	3.7 kg (8.1 lbs)	DVI-D	1x
		Display Port (DP++ 1.2)	1x
		Ethernet Ports	4x
		USB2.0	4x
		USB3.0	4x
		Interface modules such as CAN/NMEA	Optional
		COM/COM and DIO	

Power Specifications		Operating Conditions	
Power supply	Multi Power: 100-240VAC 50/60Hz and 24VDC	Operating temperature	-15°C to +55°C ¹
		Operating humidity	Up to 95%
		Storage temperature	-20°C to +60°C
		Storage humidity	Up to 95%
		Compass safe distance	Std: 30 cm / Steering: 25 cm

Norms/Standards	
IEC 60945 (2002), IACS E10, EN55024, EN55022 Class A, EU-RO-MR - Mutual Recognition	AlphaMINDS Computer
IEC 61162 series	NMEA Definitions
IEC 62288 (2014)	

Available Accessories	
CT-104 GNSS-receiver	G-009636
GNSS High-Precision Multi-band Surveying RTK antenna	G-021655

¹ Although the test conditions provide for a maximum operation temperature of 55°C, continuous operation of all electronic components should, if possible, take place at ambient temperature of 25°C. This is necessary for a long life and low service costs.

Appendix B: AlphaMINDS inputs

Sensor	Source	Sentence	Required
AIS	IEC 61162-1/2	--VDM	Optional for app Docking
	IEC 61162-450		
Anemometer	IEC 61162-1/2	--MWV	Required for app Conning
	IEC 61162-450		
Auto Pilot	IEC 61162-1/2	--HTD	Required for app Conning
	IEC 61162-450		
Bow Thruster	IEC 61162-1/2	--TRD OR --XDR	TRD or XDR or Modbus TCP. Load and/or RPM. If load or RPM is not available a conversion table can be configured. (Required if available)
	IEC 61162-450	16-bit register Load	
	Modbus TCP	16-bit register RPM	
Climate Meter	IEC 61162-1/2	--MTW	Required for app Conning
	IEC 61162-450		
	IEC 61162-1/2	--XDR	
	IEC 61162-450		
Distance Above Water	IEC 61162-1/2	--DPT	Optional for app Docking
	IEC 61162-450		
	Modbus TCP	16-bit register distance	
Distance Below Water	IEC 61162-1/2	--DPT	Optional for app Docking
	IEC 61162-450		
	Modbus TCP	16-bit register distance	
ECDIS	IEC 61162-1/2	--BWC	Required for app Conning
	IEC 61162-450		
	IEC 61162-1/2	--RTE AND --WPL	Optional for app Docking
	IEC 61162-450		
Echo Sounder	IEC 61162-1/2	--DPT	Required for app Conning
	IEC 61162-450		
Engine/Shaft	IEC 61162-1/2	--RPM OR --XDR	RPM or XDR or Modbus TCP. Load and/or RPM. Angle and/or percent. If load or RPM is not available a conversion table can be configured. If angle or percent is not available a conversion table can be configured. (Required if available)
	IEC 61162-450		
	Modbus TCP	16-bit register Engine Load	
		16-bit register Engine RPM	
		16-bit register Shaft Load	
		16-bit register Shaft RPM	
16-bit register Prop. Pitch Angle			
16-bit register Prop. Pitch Percent			
GPS	IEC 61162-1/2	--GGA	Required (At least 1 GGA and VTG source required from GPS and GPS Compass)
	IEC 61162-450		
	IEC 61162-1/2	--VTG	
	IEC 61162-450		

Continues on next page

Continued from previous page				
Sensor	Source	Sentence	Required	
GPS Compass	IEC 61162-1/2	--GGA	Required (At least 1 GGA and VTG source required from GPS and GPS Compass)	
	IEC 61162-450			
	IEC 61162-1/2	--VTG		
	IEC 61162-450			
	IEC 61162-1/2	--THS OR --HDT		Optional (At least 1 THS or HDT source required from GPS Compass or Gyro Compass)
	IEC 61162-450			
	IEC 61162-1/2	--ROT		Optional (At least 1 ROT source required from GPS Compass, Gyro Compass or Turn Indicator)
IEC 61162-450				
Gyro Compass	IEC 61162-1/2	--THS OR --HDT	Required	
	IEC 61162-450			
	IEC 61162-1/2	--ROT	Optional	
	IEC 61162-450			
Magnetic Compass	IEC 61162-1/2	--HDG	Optional	
	IEC 61162-450			
Rudder	IEC 61162-1/2	--RSA OR --XDR	RSA or XDR or Modbus TCP. Angle and/or percent. If angle or percent is not available a conversion table can be configured. (Required if available)	
	IEC 61162-450			
	Modbus TCP	16-bit register Angle		
16-bit register Percent				
Speed Log	IEC 61162-1/2	--VHW		Required for app Conning
	IEC 61162-450			
	IEC 61162-1/2	--VBW		
	IEC 61162-450			
	IEC 61162-1/2	--VLW		
	IEC 61162-450			
Stern Thruster	IEC 61162-1/2	--TRD OR --XDR	TRD or XDR or Modbus TCP. Load and/or RPM. If load or RPM is not available a conversion table can be configured. (Required if available)	
	IEC 61162-450			
	Modbus TCP	16-bit register Load		
		16-bit register RPM		
Turn Indicator	IEC 61162-1/2	--ROT	Required (At least 1 ROT source required from GPS Compass, Gyro Compass or Turn Indicator)	
	IEC 61162-450			
Vessel Clock	IEC 61162-1/2	--ZDA	Optional	
	IEC 61162-450			

Appendix C: AlphaMINDS alerts

Title	Description	Type
Invalid AIS	No valid NMEA data for AIS 1	Caution
Invalid AIS	No valid NMEA data for AIS 2	Caution
Invalid data	No valid data for Anemometer 1	Caution
Invalid data	No valid data for Anemometer 2	Caution
Invalid data	No valid data for Auto Pilot 1	Caution
Invalid data	No valid data for Auto Pilot 2	Caution
Invalid data	No valid data for Bow Thruster 1	Caution
Invalid data	No valid data for Bow Thruster 2	Caution
Invalid data	No valid data for Bow Thruster 3	Caution
Invalid data	No valid data for Bow Azi Thruster 1	Caution
Invalid data	No valid data for Bow Azi Thruster 2	Caution
Invalid data	No valid data for Climate Meter 1	Caution
Invalid data	No valid data for Climate Meter 2	Caution
Invalid distance	No valid data AFWF	Caution
Invalid distance	No valid data AWPSB	Caution
Invalid distance	No valid data AWSBB	Caution
Invalid distance	No valid data AWPSS	Caution
Invalid distance	No valid data AWSBS	Caution
Invalid distance	No valid data AWBW	Caution
Invalid distance	No valid data BFWF	Caution
Invalid distance	No valid data BWPSB	Caution
Invalid distance	No valid data BWSBB	Caution
Invalid distance	No valid data BWPSS	Caution
Invalid distance	No valid data BWSBS	Caution
Invalid distance	No valid data BWBW	Caution
Invalid data	No valid data for ECDIS 1	Caution
Invalid data	No valid data for ECDIS 2	Caution
Invalid data	No valid data for Echo Sounder FORE	Caution
Invalid data	No valid data for Echo Sounder MID	Caution
Invalid data	No valid data for Echo Sounder AFT	Caution
Invalid data	No valid data for Engine 1	Caution
Invalid data	No valid data for Engine 2	Caution
Invalid data	No valid data for GPS 1	Caution
Invalid data	No valid data for GPS 2	Caution
Invalid data	No valid data for GPS Compass 1	Caution
Invalid data	No valid data for GPS Compass 2	Caution
Invalid data	No valid data for Gyro Compass 1	Caution
Invalid data	No valid data for Gyro Compass 2	Caution
Invalid data	No valid data for Magn. Compass 1	Caution
Invalid data	No valid data for Magn. Compass 2	Caution
Invalid data	No valid data for Rudder 1	Caution
Invalid data	No valid data for Rudder 2	Caution
Invalid data	No valid data for Speed Log 1	Caution
Invalid data	No valid data for Speed Log 2	Caution
Invalid data	No valid data for Stern Thruster 1	Caution
		Continues on next page

Continued from previous page		
Invalid data	No valid data for Stern Thruster 2	Caution
Invalid data	No valid data for Stern Thruster 3	Caution
Invalid data	No valid data for SternAziThruster 1	Caution
Invalid data	No valid data for SternAziThruster 2	Caution
Invalid data	No valid data for ROTIndicator 1	Caution
Invalid data	No valid data for ROTIndicator 2	Caution
Invalid data	No valid data for Vessel Clock 1	Caution
Invalid data	No valid data for Vessel Clock 2	Caution
Invalid position	No valid position available	Caution
Invalid heading	No valid heading available	Caution
Invalid ROT	No valid ROT available	Caution

Appendix D: DOP values and their rating

DOP value	Rating	Description
<1	Ideal	Highest possible confidence level to be used for applications demanding the highest possible precision at all times.
1–2	Excellent	At this confidence level, positional measurements are considered accurate enough to meet all but the most sensitive applications.
2–5	Good	Represents a level that marks the minimum appropriate for making accurate decisions. Positional measurements could be used to make reliable in-route navigation suggestions to the user.
5–10	Moderate	Positional measurements could be used for calculations, but the fix quality could still be improved. A more open view of the sky is recommended.
10–20	Fair	Represents a low confidence level. Positional measurements should be discarded or used only to indicate a very rough estimate of the current location.
>20	Poor	At this level, measurements should be discarded.

All over the world,
close to the customer

JRC/Alpatron Marine

Schaardijk 23 (harbor 115)
3063 NH Rotterdam
The Netherlands

The information in this document is subject to change without notice and does not represent a commitment on the part of Alpatron Marine B.V.

T +31 10 453 4000
F +31 10 453 4010
service@alphatronmarine.com
www.jrc.am

Document : Installation and Operation Manual
Project no. : AlphaMINDS Conning and Docking
Version : V1.0
© All rights reserved Alphatron Marine B.V.

Centers of Excellence

Houston, Rotterdam, Singapore, Tokyo